1 What is Device Detector?

Device Detector is a memory-resident program. When OM Digital Solutions Digital Voice Recorder is connected to a PC, the corresponding application will start automatically. Regarding the recorder and corresponding application, refer to the About the auto detect application.

While Device Detector is running, the  icon will appear in the task tray.

If you right-click on the icon, a menu will appear, and you can set up the auto detect application.

The items for each menu are as follows:

Menu	Description
Setting…	The dialog box to set auto start for an application will appear. (About the auto detect application)
Topic search	Help display
Version information	Device Detector version information
Exit	Exit the program

2 About the Auto Detect Application

To set auto start for an application, right-click on the Device Detector icon and select [Settings].

In the Settings dialog box, check the application to which you want to apply the auto start.

Application Software	Supported Recorders
• Olympus Dictation Management System	DS-9000/9500/DS-7000/5500/5000/5000iD/3500/3400/2800/2600/2500/2400 RM-4110S/4100S/4015P/4010P/4000P

© 2021 OM Digital Solutions Corporation